



It is the responsibility of the installer to meet all code and safety requirements as well as o permits. The installer should determine and implement appropriate installation techniques The Fortress Company and its distributors shall not be held liable for improper or unsafe i

Read Instructions Completely Before Starting Installa

Note

Not following the below steps could result in oxidation at cut points and will void the warran Products, complete the following at cut points:

- Cut material to length and remove all metal shavings from the cut area
- File any sharp edges left by cutting. Thoroughly wipe and remove any filings, grime or dirt from the panel.
- Apply two coats of Fortress zinc based touch-up paint to the cut area. If touch up is at rail ends, allow paint to dry before connecting bracket to post.
- Be sure to remove any metal shavings from the work surface to prevent oxidation on the surface.

Required Materials

Metal Cutting Saw, File, Brush or Rags, Cardboard, Fortress Zinc Based Touch-Up Paint.

