Field Fence Spacing Configurations 12" Stay 6" Stay Opening Opening 8" 7" 6"

